

INSTRUCTIONS FOR P/N 026A WIDEFOOT FRONT
END AND P/N 062A STD. WIDTH RC-10 SHOCK MT.

The #4 washers are to go on the 4-40 allen head cap screws, which then bolt the TriDirComp shock mount to the nylon blocks.