



# QUICK CHARGER

## OPERATING INSTRUCTIONS

### WARNING

RUN YOUR CAR UNTIL THE BATTERIES ARE COMPLETELY DISCHARGED. CHARGING PARTIALLY DISCHARGED BATTERIES CAN OVERCHARGE AND DAMAGE THEM.

*NEVER OVERCHARGE BATTERIES.*


1. Be sure your model's ON-OFF switch is OFF.
2. Move the charger's selector switch to the 6 cell position. If the switch is moved to the 5 cell position, the 6 cell light will turn on but your battery will receive **no charge**.
3. Plug the charger's output connector into the socket at the rear of your model.
4. Plug the charger's lighter plug into the lighter outlet of your automobile.
5. Set the timer for a fifteen minute cycle, and then repeat the cycle for an additional fifteen minutes. A ticking should be heard from the timer and the light on the charger should remain on until each cycle is completed.
6. After the completion of both cycles, your batteries should be fully charged. Do not charge beyond the required 30 minutes or you may damage your batteries.

- CAUTION:
- Operating the charger while your automobile is running may overcharge and damage batteries.
  - Do not obstruct the timer knob during operation or you may overcharge the batteries.

KEEP YOUR CHARGER CLEAN AND DRY. DO NOT OPEN THE CASE OR ATTEMPT TO REPAIR THE UNIT. SEND THE CHARGER TO COX HOBBIES INC. FOR MAINTENANCE AND REPAIR.

COX HOBBIES INC. 1505 East Warner Avenue, Santa Ana, California 92702

a subsidiary of LEISURE DYNAMICS, INC.



If you run into problems not covered by these instructions call the  
**COX ACTION HOT LINE.**



### **SAFETY PRECAUTIONS**



- DO NOT get oil, water or dirt into charger; may result in short circuit.
- NEVER tamper with or try to disassemble your charger.
- For longer battery life DO NOT overcharge.
- Charge ONLY completely discharged battery.
- Periodically examine charger for potential hazards that may result from abuse to charger. Check case and plugs for fractures. Check wires for damaged insulation and exposed metal wires. If these conditions exist, replace this unit.

## **WARNING**

Improper use of this product may  
result in personal injury or  
damage to the product

**READ THE FOLLOWING INSTRUCTIONS  
CAREFULLY!**

You are responsible for the safe  
operation of this product.

## **COX ACTION HOT LINE...**

for advice from the men who built your boat.

AVAILABLE ONLY IN  
CONTINENTAL U.S.A.

IN CANADA CONTACT:


LEISURE DYNAMICS OF CANADA, LTD.  
1315 Lawrence Ave., E., Don Mills, Ont.

## **CALL US FREE**

### **800-854-3544**

FROM CALIFORNIA CALL 1-800-432-7277

**COX HOBBIES INC., 1505 East Warner Avenue, Santa Ana, California 92702**

● a subsidiary of LEISURE DYNAMICS, INC. 



# BATTERY CHARGERS

WE RECOMMEND YOU USE THE **COX QUICK CHARGER (CAT. NO. 900553)** WHICH IS ESPECIALLY DESIGNED TO CHARGE THE 6 CELL 1200 MAH RECHARGEABLE BATTERY PACK INCLUDED WITH COX PRO SERIES HIGH SPEED RACING CARS. IT OPERATES FROM ANY AUTOMOBILE 12 VOLT LIGHTER RECEPTACLE AND WITH ITS WIND-UP TIMER, AUTOMATICALLY PROVIDES A COMPLETE CHARGE IN LESS THAN 30 MINUTES.

OTHER CHARGERS, SUCH AS THOSE FROM LEISURE AND JOMAC, ARE COMPATIBLE WITH YOUR COX BATTERIES IF USED PROPERLY. A SPECIAL ADAPTOR IS PROVIDED WITH YOUR CAR TO ENABLE YOU TO USE THESE CHARGERS.

IF YOU INTEND TO USE OTHER THAN THE **COX QUICK CHARGER**, FOLLOW THESE INSTRUCTIONS CAREFULLY:

## INSTRUCTIONS

**IMPORTANT:** It is **imperative** that you determine the polarity (positive/negative) of the output wires from your battery charger. This should be done with a voltmeter or by instructions from your hobby dealer. Failure to identify the wires properly may result in damage to your batteries and your charger.

### PROCEDURE:

1. Connect the **red** wire from the adaptor to the **positive** wire from the charger.
2. Connect the **black** wire from the adaptor to the **negative** wire from the charger. **CAUTION:** Do not touch the red and black wires together or they will short-out.
3. Plug the adaptor into the back of the car.
4. Before connecting your charger to the power source, make sure it is set to charge 6 cell (7.2 volt) power packs and that the wire connections are not shorted.
5. Follow the operating instructions for your charger completely. Please read the warnings included with these instructions.